

Features

- 27-inch minimum base cabinet width.
- Single bowl.
- 9-inch depth.
- Three faucet holes.
- Bowl slopes 2 degrees toward drain to minimize water pooling.
- Offset drain increases workspace in the sink and storage space underneath.
- Includes stainless-steel bottom sink rack.
- Small size fits compact spaces.

Material

• KOHLER[®] enameled cast iron.

Installation

Top-mount

Recommended Products/Accessories

K-9000 P-Trap K-6238 Sink Rack K-6377 Sponge Caddy K-6378 Kitchen Brush Caddy K-6379 Kitchen Squeegee K-6382 Disinfecting Wipes Dispenser K-6383 Soap Dispenser K-8618 Paper Towel Holder K-8619 Flexible Kitchen Mat K-8624 Dish Scraper K-8801 Sink Strainer K-8799 Sink Strainer

Optional Products/Accessories

K-6194 Utility Rack With Soaking Cup K-6239 Colander with Cutting Board K-6246 Cutting Board

Included Components

Product consists of: K-6238 Sink Rack 1054375 Under-mount Sink Kit, 23"



Riverby[®]

K-5872-3A1

Top-mount Kitchen Sink

Codes/Standards

ASME A112.19.1/CSA B45.2

KOHLER[®] Enameled Cast Iron Kitchen Sink Lifetime Limited Warranty

See website for detailed warranty information.


Available Colors/Finishes

Color tiles intended for reference only.

Color	Code	Description
	0	White
	FF	Sea Salt™
	96	Biscuit
	47	Almond
	FD	Cane Sugar™
	95	lce™ Grey
	G9	Sandbar
	K4	Cashmere
	20	Suede
	KA	Black 'n Tan
	7	Black Black™








Technical Information

All product dimensions are nominal.			
Bowl configuration:	Single		
Installation:	Top-mount		
Min. base cabinet width:	25" (635 mm)		
Bowl area (Only):	Length: 22-1/4" (565 mm) Width: 15-13/16" (402 mm) Bowl depth: 9" (229 mm)		
Number of deck holes:	3		
Faucet hole(s):	1-3/8" (35 mm)		
Drain hole:	3-7/8" (98 mm)		
Template:	1172565-7, required, included		



Notes

Install this product according to the installation instructions.

NOTICE: Countertop manufacturer or cutter must use the cut-out template provided with the product, or a current one provided by Kohler Co. (call 1-800-4-KOHLER). Kohler Co. is not responsible for cutout errors when the incorrect cut-out template is used.

IMPORTANT! Use of the colander, wood cutting board, and utility rack requires the "reveal" cutout option on the cutout template.

